
# Outside Mount on Face of Wall Manual push up Operation



View from Coil Side




Shown without Hood option Shown with Keylock option

## Outside Mount on Face of Wall Manual push up Operation - Details



View from Coil Side



Shown without Hood option Shown with Thumb Turn option

## Outside Mount on Face of Wall Motorized Operation



View from Coil Side




Shown without Hood option

## Outside Mount on Face of Wall Motorized Operation - Details



View from Coil Side




Shown without Hood option

## Outside Mount on Face of Wall Hand Crank Operation



View from Coil Side




Shown without Hood option Shown with Keylock option

### Outside Mount on Face of Wall Hand Crank Operation - Details




View from Coil Side



Shown without Hood option Shown with Slide Bolt option


#### End Plate size details






### Outside Mount on Face of Wall

### Manual push up, Motorized and Hand Crank Operation







### Outside Mount on Face of Wall

