
Inside Mount Under Lintel Manual push up Operation



View from Coil Side




Shown without Hood or Fascia option Shown with Keylock option

Inside Mount Under Lintel Manual push up Operation - Details



View from Coil Side




Shown without Hood or Fascia option Shown with Thumb Turn option

Inside Mount Under Lintel Motorized Operation



View from Coil Side




Shown without Hood or Fascia option

Inside Mount Under Lintel Motorized Operation - Details



View from Coil Side




Shown without Hood or Fascia option

Inside Mount Under Lintel Hand Crank Operation



View from Coil Side




Shown without Hood or Fascia option Shown with Keylock option

Inside Mount Under Lintel Hand Crank Operation - Details




View from Coil Side




Shown without Hood or Fascia option Shown with Thumb Turn option


End Plate size details






Inside Mount Under Lintel









Inside Mount Under Lintel

