



Woodfold Mfg., Inc.
1811 18th Ave
Forest Grove, OR 97116
woodfold@woodfold.com
503-357-7181
Fax: 503-357-7185
www.woodfold.com

Accordion Doors Upkeep & Care Suggestions

Operation & Maintenance:

- For proper operation the track must be securely attached to the header, plumb, level & free from debris or kinks. The track may periodically lubricated with a clear petroleum based lubricant, do NOT use aerosol lubricants.
- Vertical jambs must be perpendicular for proper operation, use the installation instructions for recommended installation.
- The hinge hardware system on the top & bottom of the door may be stiff at first and will loosen over time with use, a clear petroleum based lubricant can be applied to the rivet connecting each fold to loosen the stiffness.
- During normal use of your Woodfold door watch for instances where binding during movement occurs. If there is binding, inspect the track for loose screws, dirt, debris & wheel alignment.
- Exposure to prolonged light will cause fading of the material color, long exposure to severe temperatures may cause delamination and cracking of the vinyl hinge connectors.

Care & Cleaning

- Regular cleaning of the Vinyl, Acrylic, Aluminum & Veneers-use mild soapy water then dry with a soft cloth or chamois-Do NOT use abrasive towels or scouring pads.
- Acrylic & Aluminum-these panels can be cleaned a non-abrasive-anti-static cleaner.
- Hardwood Veneers are made with a Sherwin Williams water based clear coat, paint or stain recommend mild soap and water for cleaning

The following disinfectants that are approved for use against SARS-CoV-2 Woodfold vinyl laminates:

- Asepticare™
- Bleach 1:5 (20% bleach)
- Bleach-Rite® Disinfecting Spray
- Clorox® Healthcare Bleach Germicidal Wipes & Cleaner
- Clorox® Healthcare Dispatch® Hospital Cleaner Disinfectant with Bleach
- Clorox® Healthcare EZ-KILL® Wipes
- Clorox® Healthcare VersaSure® Cleaner Disinfection Wipes
- Isopropanol (70%) & (91%)
- Diversey™ Accel® TB
- Lysol® Disinfectant Spray
- Oxivir® 1 RTU
- Oxivir® TB
- OxyCide™ Daily Disinfectant Cleaner
- PDI Super Sani-Cloth® AF3 Germicidal Disposable Wipes
- PDI Super Sani-Cloth® Bleach Germicidal Disposable Wipes
- Virex II 256
- Virox AHP 5
- Wex-Cide 128



An Employee-owned Company

Crafting Value For More Than 60 Years.